



Where technology and experience work together

Ph: 765-795-3319
Mail: 352 N Main St.
Cloverdale, IN 46120
Web: <http://www.XscapeEz.com>

GETTING STARTED WITH EZ TAP

The Ez TAP – Truck Access Point system is designed to provide RP1210 OEM diagnostics coupled with new and exciting fleet management features exclusive to Ez TAP. Included on this CD are several installations and documents to guide you through setup process depending on your application.

Documents on this CD		
NAME	Information	CD Directory Location
<i>Getting Started with Ez TAP.pdf</i>	Introductory info	Root Directory
<i>Quick Start Guide.pdf</i>	New installation setup guide	Root Directory
<i>EZ1210_Driver_Only_Install.pdf</i>	RP1210 driver only installation	EZ1210 DLL Only Installation
RF_Base_Driver_Install.pdf	Kernel drivers for manual installation of RF base units	RF Base Drivers
Ez_TAP_Brochure.pdf	Overview of Ez TAP features	Root Directory

Installations on this CD		
NAME	Information	CD Directory Location
<i>EZ TAP Automated Inatall.exe</i>	All new installations and all new RF base configurations	Root Directory
<i>EZ1210 Driver Install.exe</i>	RP1210 driver only installation	EZ1210 DLL Only Installation
Individual kernel driver install files for use with the Windows Device Manager	Kernel drivers for manual installation of RF base units	RF Base Drivers

Technical Support Contact Information:

support@xscapeez.com
(765) 795-3319